

HONDA DISTRIBUTOR



TD-31U
OEM#
30100-PT3-A03/30100-PT3-A72
DESCRIPTIONS
Honda Accord 91-90



TD-01U
OEM#
30100-PM5-A04
DESCRIPTIONS
Honda Civic, CRX, Wagovan 89-88



TD-42U
OEM#
30100-P08-006
DESCRIPTIONS
Honda Civic, Civic Del Sol 95-92



TD-61U
OEM#
30100-P14-A01
DESCRIPTIONS
Honda Prelude 95-92



TD-80U
OEM#
30100-P2E-A01
DESCRIPTIONS
Honda Civic, Civic Del Sol 98-96



TD-97U
OEM#
30100-P3F-A02
DESCRIPTIONS
Honda CRV 98-97



TD-91U
DESCRIPTIONS
Honda Accord 02-98



TD-52U
OEM#
30100-P12-A01/30100-PT3-A12
DESCRIPTIONS
Honda Accord 93-92



TD-41U
OEM#
30100-P06-A02
DESCRIPTIONS
Honda Civic, Civic Del Sol 95-92



TD-52U
OEM#
30100-P0JA01
DESCRIPTIONS
Honda Accord, Prelude 95-92

HONDA DISTRIBUTOR



TD-76U
OEM#
 30100-P0B-A01
DESCRIPTIONS
 Honda Accord, Prelude 97-96



TC-08A
OEM#
 30100-P6T-T01/30100-P6T-T01
DESCRIPTIONS
 Honda CRV 01-99



TD-97U
OEM#
 30100-P2E-A11
DESCRIPTIONS
 Honda Civic 00-99



TD-60U
OEM#
 300-P13-006
DESCRIPTIONS



TD-73U
OEM#
 22100-3S400
DESCRIPTIONS
 NISSAN L16/L18



TD-01U
OEM#
 30100-PM5-A07
DESCRIPTIONS
 Honda Civic, CRX 91-90



TD-02U
OEM#
 30100-PM6-A04
DESCRIPTIONS
 Honda Civic, CRX 91-90



D4T96-03
OEM#
 30100-PAA-A02
DESCRIPTIONS
 Honda Accord 02-98



D4J92-04
OEM#
 30100-P0A-A02
DESCRIPTIONS
 Honda Accord 95-94



TD-22U
OEM#
 30100-PR-024

HONDA DISTRIBUTOR



TD-30U
DESCRIPTIONS
ACCORD 2.0L/F20A



TD-40U
OEM#
30100-P04-G02
DESCRIPTIONS
CIVIC/CRX



TD-43U
OEM#
30100-P29-006



TD-89U
DESCRIPTIONS
DOHC.VTEC.H22A

www.rskignition.com

www.rskignition.com

www.rskignition.com

www.rskignition.com

www.rskignition.com

www.rskignition.com